



USB Programming Guide - RS 485

Additional Parts in the Box



Programming Dongle



USB to SDN cable



Thumb Drive with SDN
Tools Software and
Programming Instructions

1. Install Somfy Motor Configuration Software on a Windows PC. Use the included USB thumb drive or scan the QR code on the cable to download another copy.
2. Connect the USB programming cable to the RJ45 connector on the included Programming Dongle, and then connect your Shade Terminal from your screen to the white terminal block header on the same dongle, and finally connect the Shade Power supply (or pre wire from your Power panel to the green terminal connection on the dongle).
3. Open the Somfy SDN Motor Configuration Software, and select the USB cable com port from the upper left box, and now click on get single motor address and you are ready to set your limits. The complete manual for programming with this cable is also on the USB drive.

