

# Applying Zigbee RMA shade back to your network



## Initial Considerations

CAUTION: it is essential to read and fully understand this instruction set before adding any products back to an existing Screen Innovations ZigBee 3.0 network.

This instruction set describes the procedure to add a pre-configured ZigBee 3.0 Nano roller shade or Drapery track back to an existing Screen Innovations ZigBee 3.0 network.

Additional resources including tech notes, design guides, and training videos are available at [support.screen-innovations.com](http://support.screen-innovations.com). Give us a call at (512) 832 –6939 option 1 for technical support.

## Add a Roller Shade

1. Unpack the new/replacement roller shade
2. Install the shade in its final location
3. Open the TaHoma application on the Client's tablet or smartphone
4. On the homepage, locate the name of the RMA shade and test the commands to see if the shade responds.
5. If the shade responds, Congratulations, you are all set.
6. If the shade does not respond, connect the included charging cable to the charging port.
7. Now follow the step 4.

**Do not hold the motor head button for longer than 2 jogs.**